

EN - Safety instructions - Installation instructions

Ena LED

1- Installation and commissioning may only be carried out by authorized specialists. Electrical components must be connected by qualified electrician.

2- BEWARE! Make sure the luminaires are always disconnected from the mains supply during wiring, installation and maintenance work. Before starting the installation, make sure the power is switched off.

3- This fixture is suitable for indoor wall/ ceiling or for cove lighting use. The luminaire is exclusively used for lighting and is to be installed in accordance with the national regulations. Any other use or installation is regarded as "non according to instructions".

4- The luminaire with F mark are suitable for installation on normally flammable surfaces (for example wood and wood-based materials of more than 2 mm thickness).

5- Do not put the luminaire on surfaces that are wet, recently painted or on electrical connections.

6- Always be sure to keep a minimum spacing of more than 0.5m (50cm) between the luminaire and the illuminated surface.

7- Do not cover the luminaire. Do not hang anything from the luminaire.


8- Ceiling and wall installation:
Take off the luminaires acrylic diffuser.
Mark the points of interest for the holes
Make the holes for screw with diameter head 4 mm.
Place the luminaire
Insert back the acrylic diffuser.

9- Cleaning is limited to the external parts of the luminaire. Do not clean under high pressure.

Protection class I. Operation insulation and protection earthing of all touchable and conductive parts. The lighting is determined to a connection with a protective conductor which is labelled with the appropriate test symbol.



IP44



KEEP THESE INSTRUCTIONS FOR FURTHER REFERENCE.