


### Tholos Ceiling LED

- 1- Installation and commissioning may only be carried out by authorized specialists. Electrical components must be connected by qualified electrician.
  - 2- BEWARE! Make sure the luminaries are always disconnected from the mains supply during wiring, installation and maintenance work. Before starting the installation, make sure the power is switched off.
  - 3- This fixture is suitable for indoor wall/ ceiling or for cove lighting use. The luminaire is exclusively used for lighting and is to be installed in accordance with the national regulations. Any other use or installation is regarded as "non according to instructions".
  - 4- The luminaire with F mark is suitable for installation on normally flammable surfaces (for example wood and wood-based materials of more than 2 mm thickness).
  - 5- Do not put the luminaire on surfaces that are wet, recently painted or on electrical connections.
  - 6- Always be sure to keep a minimum spacing of more than 0.5m (50cm) between the luminaire and the illuminated surface.
  - 7- Do not cover the luminaire. Do not hang anything from the luminaire.
  - 8- Ceiling and wall installation:  
Make a hole of 165 mm diameter.  
Connect the power supply cables to the drive and place it in the ceiling.  
Push up the springs of the fitting and pass them through them in the hole.  
Free them springs and push up the fitting.
  - 9- Cleaning is limited to the external parts of the luminaire. Do not clean under high pressure.
- Protection class I.** The ground cable (green/yellow) must be connected. If there is not a mains supply with a protective ground wire available, the product must not be connected /used there



IP 65



KEEP THESE INSTRUCTIONS FOR FURTHER REFERENCE.