



MOUNTING AND OPERATION INSTRUCTIONS

HERMES - T5

1. HERMES is an indoor fluorescent luminaire with electronic ballast.
2. The lamp types as well as the wattage are indicated on the metal identification tag.
3. Ceiling or wall mounted luminaire
4. Power supply 230V.
5. Pass the cable through the rubber hole and connect it to the appropriate clamp according to labeling for voltage and grounding
6. **Attention** Make sure that the power is disconnected when installing the luminaire as well as during lamp changing.
7. The luminaire covers of the types **SLIM - BASIC – TWIN – LONG** may be removed by gently pulling, while the **WALLWASHER** requires a screwdriver to remove the reflector.
8. The luminaire must not be covered by papers, cloths and any combustible materials
9. Ceiling/Wall mounting

Remove the metallic fixation parts from the back of the luminaire
Place them on the mounting surface in a distance of 25cm from the edges of the luminaire and watch the placement line
There is a small tolerance of the placement through the oval opening of the metal fixation part
Be careful so that the screws on the metal fixation part are on the same side

Pass the luminaire grooves on the groove of the metal fixation part and fix the screws on the other side

10. To be installed by a certified electrician

11. Keep the instructions for future use



Class I
(Grounding required)

GALLIS S.A



MOUNTING AND OPERATION INSTRUCTIONS

HERMES - T5

1. HERMES is an indoor fluorescent luminaire with electronic ballast.
2. The lamp types as well as the wattage are indicated on the metal identification tag.
3. Ceiling or wall mounted luminaire
4. Power supply 230V.
5. Pass the cable through the rubber hole and connect it to the appropriate clamp according to labeling for voltage and grounding
6. **Attention** Make sure that the power is disconnected when installing the luminaire as well as during lamp changing.
7. The luminaire covers of the types **SLIM - BASIC – TWIN – LONG** may be removed by gently pulling, while the **WALLWASHER** requires a screwdriver to remove the reflector.
8. The luminaire must not be covered by papers, cloths and any combustible materials
9. Ceiling/Wall mounting

Remove the metallic fixation parts from the back of the luminaire
Place them on the mounting surface in a distance of 25cm from the edges of the luminaire and watch the placement line
There is a small tolerance of the placement through the oval opening of the metal fixation part
Be careful so that the screws on the metal fixation part are on the same side

Pass the luminaire grooves on the groove of the metal fixation part and fix the screws on the other side

10. To be installed by a certified electrician

11. Keep the instructions for future use



IP20 Class I
(Grounding required)

GALLIS S.A