

EN - Safety instructions - Installation instructions

Zeus

1- Installation and commissioning may only be carried out by authorized specialists. Electrical components must be connected by qualified electrician.

2- BEWARE! Make sure the luminaries are always disconnected from the mains supply during wiring, installation and maintenance work. Before stating the installation, make sure the power is switched off.

3- This fixture is suitable for indoor or outdoor use. The luminary is exclusively used for lighting and is to be installed in accordance with the national regulations. Any other use or installation is regarded as "non according to instructions".

4- The luminary with F mark is suitable for installation on normally flammable surfaces (for example wood and wood-based materials of more than 2 mm thickness).

5- Do not put the luminary on surfaces that are wet, recently painted or on electrical connections.

6- Always be sure to keep a minimum spacing of more than 0.5m (50cm) between the luminary and the illuminated surface.

7- Do not cover the luminaire. Do not hang anything from the luminaire.

8- Ceiling and wall installation:

There are 4 to 8 plastic lockers that hold the cover. Make **4 holes** in the ceiling / wall. Use the adequate **plastic anchors and screws** to fix the luminaire.


Connect the mains cable to the luminaire. Insert the lamps and close the luminaire. Lock it.

9- Cleaning is limited to the external parts of the luminary. Do not clean under high pressure.

Protection class I. The ground cable (green/yellow) must be connected. If there is not a mains supply with a protective ground wire available, the product must not be connected /used there



IP65



KEEP THESE INSTRUCTIONS
FOR FURTHER REFERENCE.